BLIP TESTING PROCEDURE VAMP/LOCKIN:BOARD #		8 Oct. 1998 DATE		
V AMP 1:				
 Test connections: For the <u>V AMP test</u> measure the V MON connectors on the front panel. For the <u>VAMP/LOCKIN test</u> obse on front panel and LOCKIN 1 output o PS1 Bias in conjunction with a determinant of the property of	erve the LOCKIN output the Breakout Box. ector simulator(a resist	out at LOCKIN 1 OUT		
2. Power up settings:3. Test preparation settings:	AZ FAS	FAST: 1(on)		
readfile vamp.macroSet DAC = $1V$ $PS1DAC(1)$ Select the $1kHz$ ref.: $refPS1(0)$ Filter output: $filterPS1$ Undivide output: $divPS1(0)$ Unground QI: $gndPS1(0)$	REF SE FILTER DIVIDE GND PS	` /		
Unselect variable input: varPS1(0) Select Mux 1 output: Mux1(Vamp1) 4. V AMP test: Input settings in Step 3 before starting to	est. $\overline{\text{Vin}} = 1\text{V}$ Enter the	For manual input testing: Vin = 1Vp-p sine wave Enter the following settings: PS1DAC(0) VarPS1		
Turn Phonon Sensor 1 pot. on BOB fully clockwise Vamp out = 1Vp-p				
Is PS1 VAMP OUT a 1kHz sine w What is the maximum amplitude				
Change the potentiometer setting randomly	over its range of trav	el.		
Does the amplitude of PS1 VAM Are the Vamp and Mux outputs	_			
5. VAMP/LOCKIN test: Input settings in Step 3 and verify step 4	results before starti	ng test.		
Vary pot setting and observe LOCKIN 1 O	OUT.			
Does LOCKIN 1 OUT level change corresponding changes in the corresponding changes c	_			

BLIP TESTING PRO VAMP/LOCKIN:BO							
If "NO" then conduct LOCKIN TEST procedures.							
Turn on Lockin Bypass: bypass							
Does the LOCKIN 1 OUT change to a sine wave?							
Turn off Lockin Bypass: bypass(0) Verify return of original output							
V AMP 2 :							
 MON connectors on the For the <u>VAMP/LO</u> on front panel and LOC 	e front panel. CKIN test observe CKIN 2 output on output with a detect	re the LOCKIN out the Breakout Box. or simulator(a resis	VAMP OUT, and MU tput at LOCKIN 2 OU stor divider network a the input signal.	JT.			
Set mux 1 to output PS2 VAMP OUT: Mux1(Vamp2)							
2. Power up settings:3. Test preparation settings	nge	AZ FA V AMI	IN BYPASS 2: 0(off) AST: 1(on) P FAST: 1(on) REF 2: 0(off)				
3. Test preparation setting	ugs.						
readfile vamp.macro Set DAC = 1V Select the 1kHz ref.: Filter output: Undivide output: Unground QI: Unselect variable input: Select Mux 2 output:	PS2DAC(1) refPS2(0) filterPS2 divPS2(0) gndPS2(0) varPS2(0) Mux2(Vamp2)	REF S FILTE DIVID GND F	DE: 0(off)				
4. V AMP test: Input settings in Step 3 be Turn Phonon Sensor pot. of	G	Vin Ente	manual input testing: = 1Vp-p sine wave or the following settings:	PS1DAC(0) VarPS1			
Is PS2 VAMP OUT a What is the maximum		ve?	np out = 1Vp-p				

Change the potentiometer setting randomly over its range of travel.

BLIP TESTING PROCEDURE VAMP/LOCKIN:BOARD #		8 Oct. 1998 DATE				
Does the amplitude of PS2 VAMP OUT change? Are the Vamp and Mux outputs equal?						
5. VAMP/LOCKIN test: Input settings in Step 3 and verify step 4 results before starting test.						
Vary pot setting and observe LOCKIN 2 OUT.						
Does LOCKIN 2 OUT level change in amplitude with corresponding changes in the pot setting? If "NO" then conduct LOCKIN TEST procedures.						
Turn on Lockin Bypass: bypass						
Does the LOCKIN 2 OUT change t	o a sine wave	9?				
Turn off Lockin Bypass: bypass(0)						